

Welcome to the Firefly family! Our top priority is to give you the best experience and value from your purchase. Please carefully read through the manual to enjoy your new Firefly product.

### SAFETY AND GENERAL INFORMATION




This product should be used only in accordance with the specifications listed in this manual. Usage beyond what is specified here may result in serious injury.

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons including the following:

- For your safety, read the manual and safety instructions before use.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not operate this product unless the power source is within the specified rated voltage.
- Keep the cords away from cluttered areas. To avoid fire or shock hazard, NEVER place the cord under combustible materials, near stoves or heaters.
- Do not pull the power cord excessively when unplugging it. Do not bend or damage the power cord.
- Avoid touching the power cord, plug or socket with wet hands or wet body parts.
- Do not turn on or use the product while charging to prevent abnormal heating and early battery failure.
- The product may become slightly warm during charging and this is normal.
- Do not use near flammable and explosive materials or where water and vapor are present.
- In order to prevent the fan from falling during usage, please place it on a stable flat surface.
- Do not drop or cause excessive impact to the product as this may damage your unit or may cause malfunction, shorten its lifespan or may cause overheating and risk of fire.
- If the supply cord is damaged, it must be replaced by similar cord with the correct specified current rating
- Do not attempt to repair or adjust any electrical/mechanical functions of this unit. Doing so will void the product warranty. No user serviceable parts. All servicing should be performed by a qualified personnel only.
- During storage, turn off the switch and disconnect the unit from the AC power supply followed by the DC adapter cord from the unit.
- Contact the manufacturer or a qualified technician if the product fails to function as stated on the packaging or manual.

**WARNING:** This product contains a lithium-ion battery. Do not dismantle, squeeze or put the battery on fire. If the battery appearance is abnormal (i.e. swelling, leaking, etc), discontinue use and dispose right away. Do not place the battery in hot or high temperature areas.

## PRODUCT STRUCTURE & SPECIFICATIONS



### TECHNICAL SPECIFICATIONS:

|                   |                                                                                                                                                                                                                                                                                                                                                                                                                                |
|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Item Code         | FEL815 (White)<br>FEL815BG (Beige)<br>FEL815LG (Green)                                                                                                                                                                                                                                                                                                                                                                         |
| Rated Power       | 5 Watts                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Input Voltage     | 5V DC                                                                                                                                                                                                                                                                                                                                                                                                                          |
| Battery Type      | 3.7V 1.8 Ah Lithium-Ion Battery with CID*, PRV**, PTC***<br><small>*CID (Current Interrupt Device): protects the cells under overcharge conditions<br/>**PRV (Pressure Relief Valve): prevents excessive pressure buildup when the battery is being charged, and automatically reseals once the pressure is released<br/>***PTC (Positive Temperature Coefficient): protects the cells under external short conditions</small> |
| Noise Level       | < 60 dB                                                                                                                                                                                                                                                                                                                                                                                                                        |
| Charging Time     | 3 - 4 Hours                                                                                                                                                                                                                                                                                                                                                                                                                    |
| Usage Duration    | Low : 7 Hours<br>Mid : 5 Hours<br>High: 3 Hours                                                                                                                                                                                                                                                                                                                                                                                |
| Product Dimension | 130 (L) x 108 (W) x 164 (H) mm                                                                                                                                                                                                                                                                                                                                                                                                 |

### PRODUCT FEATURES

- Mini rechargeable clip fan. It can be tilted up to 45° degrees in vertical direction.
- Three fan speed modes that suit every mood of choice.
- Desk fan and emergency fan in one with longer operating time when in battery mode.
- Hazard-free batteries, equipped with safety protection accessories (CID\*, PRV\*\* and PTC\*\*\*)
- Longer battery life and very safe to use due to built-in overcharge and over discharge protection.
- Fast charging with longer battery discharge rate for longer operation.
- Charging and full charge indicators.
- Equipped with a Type-C USB charging input port that can be charged anywhere using your power bank, car chargers and charger adaptors.

## POWER & FAN SPEED BUTTON

1. Fan operation. Press the fan switch to operate the fan. The fan will operate on the following sequence every time the fan button is pressed. Low → Mid → High → OFF. Pressing it again will make it return to its original cycle.
2. Charging the unit. Use the supplied USB cable, insert the Type-C USB plug to the USB charging port and attach the other end of the USB cable to a suitable 5VDC adaptor. It is recommended to use a 5VDC/2A adapter. Check the charging indicator to know charging status:  
STEADY RED - unit is charging,  
STEADY GREEN - fully charged

## CLEANING REMINDERS

Before cleaning, repairs and maintenance, make sure to turn off the power and unplug the unit from the power supply.

- Use a soft and damp cloth to wipe the external surface of the unit. Do not use excessive water or abrasive material during cleaning.
- Do not use gasoline, benzine, thinner, harsh cleaners, etc. on and/or in the unit while cleaning as they will damage the unit.
- Do not stick any foreign objects inside the unit.
- Never use alcohol or other solvents.

For repairs and maintenance, consider all the following details:

- To maximize the fan air flow, make sure to clean the fan grille occasionally.
- Do not put the product in unstable, flammable and wet area.
- Avoid exposing the product to heavy fumes or smoke.
- Do not immerse in water or any other liquid. This is a non-water resistant product.
- Do not alter or modify the unit, the supplier will not be responsible for any personal injury as a result of item misuse.
- To protect the validity of the warranty, do not use the product other than its intended purpose.
- Do not use the device while charging to prolong battery life.

## UNIT STORAGE

Remove the plug, pack the unit properly to prevent dust from entering the body. Store it in dry and well ventilated place.

## SERVICE AND GUARANTEE

At Firefly Electric and Lighting Corporation (FELCO), all products are rigorously tested and conform to our stringent quality standards.

This product is specifically guaranteed to be free from manufacturing defects in its original materials (including original parts and workmanship) for a period of 3 months from the date of purchase. Like all other goods, it is not impervious to damage. Hence, proper care and maintenance must be observed.

In the event that you find a problem with this product, please take note of the following:

|                           |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>IF WITHIN WARRANTY</b> | <p>Properly secure the product in its original packaging and personally return it, together with all of its accessories to the store where it was purchased. In case returned through a courier, the customer will be responsible and shoulder the related expenses.</p> <p>Please ensure to provide a copy of the dated receipt of purchase along with the filled-up warranty form below. A <b>No Receipt, No Warranty</b> policy will be implemented.</p> <p>Upon careful assessment, the product will be repaired, or replaced with a new unit if beyond repair, free of charge.</p> <p>The repaired or new unit replacement will be made available in the store where the original purchase was made and the customer will be responsible for the pick up.</p> |
| <b>IF BEYOND WARRANTY</b> | <p>Properly secure the product and return it together with all of its accessories to the FELCO Service Center located at Zen Towers, 1111 Natividad Lopez St., Ermita, Manila. The customer will shoulder all related shipping expenses and FELCO will not be responsible for loss or damage to the product while in transit to the Service Center. For added peace of mind, it is recommended to avail of a courier insurance.</p> <p>Since the product is BEYOND warranty, repair and serviceable parts costs will be charged to the customer in the event that the product can still be repaired.</p>                                                                                                                                                           |

**Warranty is only valid with a dated proof of purchase, and DOES NOT** cover normal wear and tear, accidental damage, misuse, abuse, neglect or improper repair or alteration by unauthorized persons.

**Warranty applies only to the original registered owner and DOES NOT** extend to subsequent owner/s of the product.

**Warranty is only valid within the Philippines.**

**In no event shall liability exceed the purchase price paid by the customer for this product. Under no circumstances shall there be liability for any loss, direct, indirect, incidental, special or consequential damage, arising out of or in connection with the use of this product.**

Any warranty conditions, and instructions included in the manual may be subject to change without prior notice. For the most updated warranty conditions and/or instructions, please contact us at +63 2 8789 1000 or visit our website at [www.fireflyelectric.com](http://www.fireflyelectric.com).

### WARRANTY FORM

Please fill up the details in the fields below. Cut this warranty form along the dash lines and send it together with the product and its original accessories, together with the official receipt of purchase to make a warranty claim.

|                           |                                                    |
|---------------------------|----------------------------------------------------|
| <b>Customer Name :</b>    | <b>Attach your official purchase receipt here:</b> |
| <b>Address :</b>          |                                                    |
| <b>Mobile Number :</b>    |                                                    |
| <b>Item Code :</b>        |                                                    |
| <b>Item Name :</b>        |                                                    |
| <b>Concern :</b>          |                                                    |
| <b>Date of Purchase :</b> |                                                    |

We would love to hear from you. For comments and suggestions, you can email us at [info@fireflyelectric.com](mailto:info@fireflyelectric.com)

### CORRECT DISPOSAL OF THIS PRODUCT



This marking indicates that this product should not be disposed with other household wastes. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.